

more 

NF18MESH

Quick Start Guide


FTTN/B Connections




What's in the box




1 x NF18MESH
CloudMesh Gateway




1 x RJ45
Ethernet Cable



1 x RJ11
Telephone Cable



1 x Power Supply
(12V/2A)



1 x Quick Start Guide



1 x Warranty Card
1x End User License Agreement

more 



safety information

Please Read Before Use



Location

The gateway is designed for indoor use only.

Place the gateway in a central location for the best WiFi performance.



Airflow

- Do not restrict airflow around the gateway.
- The gateway is air cooled and may overheat where airflow has been restricted.
- Always allow minimum clearance of 5cm around all sides and the top of the gateway.
- The gateway may become warm during normal use. Do not cover, do not put in an enclosed space, do not put under or behind large items of furniture.



Environment

- Do not place the gateway in direct sunlight or any hot areas.
- Safe operating temperature of the gateway is between 0° and 40°C
- Do not allow the gateway to come in contact with any liquid or moisture.
- Do not place the gateway in any wet or humid areas such as kitchen, bathroom or laundry rooms.



Power Supply

Always use only the power supply unit that came with the gateway. You should immediately stop using the power supply unit if the cable or power supply unit is damaged.



Service

There are no user-serviceable components in the gateway. Do not attempt to disassemble, repair, or modify the gateway.



Small Children

Do not leave the gateway and its accessories within the reach of small children or allow them to play with it. The gateway contains small parts with sharp edges that may cause an injury or which could become detached and create a choking hazard.



RF Exposure

The gateway contains a transmitter and a receiver. When it is on, it receives and transmits RF energy. The gateway conforms with the radio frequency (RF) exposure limits adopted by the Australian Communications and Media Authority Radiocommunications (Electromagnetic Radiation - Human Exposure) Standard 2014, when used at a distance of not less than 20 cm from the body.)



Product Handling

- Always treat the gateway and its accessories with care and keep it in a clean and dust-free place.
- Do not expose the gateway or its accessories to open flames.
- Do not drop, throw or try to bend the gateway or its accessories.
- Do not use harsh chemicals, cleaning solvents, or aerosols to clean the gateway or its accessories.
- Please check local regulations for disposal of electronic products.
- Arrange power and Ethernet cables in a manner such that they are not likely to be stepped on or have items placed on them.

Getting Started



Pre-configured?

If you received the Netcomm NF18MESH modem from More, the device will be pre-configured. Follow the steps specific to your FTTN/B NBN connection on the following pages to get connected.

more 

How to connect your Netcomm modem:

FTTN/B Connections

Getting Started

Step 1


Locate the telephone wall socket in your property that has been activated for NBN. Please note that there may be multiple telephone wall sockets in your property.

Step 2

Disconnect all equipment from your telephone sockets. This includes phones and fax machines plugged in around the property. These devices will interfere with the NBN signal

Step 3

Connect your modem to the telephone wall socket using the DSL port on the back of the Netcomm modem and power it on. It is important to use the first (main) socket at your property. If you are unsure of this, you may require a private phone technician to check your wiring.



Step 4

After you have connected the modem to the wall socket and powered it up, wait up to five minutes, after which the lights on the modem should stop flashing and become steady. This shows you that you have successfully connected the modem to the line that NBN is active on. If they don't stop flashing, you should try alternative telephone wall sockets in the property until it does.

Once successfully connected to the network, the Power, WAN & WiFi 2.4 – 5 lights will display a steady green light. The internet light will be flashing.



Final steps

After you've completed the steps to connect your NetComm NF18MESH modem, wait up to 20 mins to connect to your devices. Once connected, run a test to check the speed of your connection at www.speedtest.net

If the modem is still not connected after 20 minutes, please contact our technical support team for further assistance:

Technical Support

If you require assistance setting up your BYO device our team is available.

1800 733 368

7am – Midnight (Weekdays) AET

8am – 8pm (Weekends) AET


Overseas: [+61390219630](tel:+61390219630)

WhatsApp: [+61480096696](tel:+61480096696)


more 

How to connect a NF18MESH modem

That is not pre-configured



Logging in to the web interface

The image shows the NetComm login interface. It has a blue background with the NetComm logo in the top left corner. In the center, there is a section titled "LOGIN TO YOUR DEVICE". Below this title are two input fields: "Username" and "Password". Below the "Password" field is a blue button with the text "Login >".

NetComm

LOGIN TO YOUR DEVICE

Username

Password

Login >

1. Complete a factory reset of the modem

2. Open web browser

(such as Mozilla Firefox or Google Chrome), type <http://cloudmesh.net> into the address bar and press **Enter**.

If you encounter difficulties connecting, type <http://192.168.20.1> and press **Enter**.


3. At the login screen

Type **admin** into the **Username** field. In the **Password** field, enter the password printed on the gateway label (affixed to the back panel of the gateway) then click the **Login >** button.

Note - The graphics that appear in the section represent the display from a Windows browser. The same graphics will display differently when viewed on a hand held device.

If you're unable to login, perform a **factory reset** of the modem.

Using The First-Time Setup Wizard




Upon first login

The gateway displays the first-time setup wizard.

We recommend using the wizard to configure your Internet connection.

Click the **Yes, start the setup wizard** button.

Using The First-Time Setup Wizard



The screenshot shows the NetComm first-time setup wizard. At the top, the NetComm logo is displayed. Below it, a progress bar shows six steps: INTERNET, WIRELESS, PHONE, GATEWAY SECURITY, TIMEZONE, and SUMMARY. The INTERNET step is currently selected and highlighted. Under the INTERNET SERVICE section, there are three radio button options: ADSL, VDSL (which is selected), and Ethernet WAN. Under the CONNECTION TYPE section, there are four radio button options: PPPoE (which is selected), Dynamic IP, Static IP, and Bridge. Below these options are input fields for Username and Password. There are also input fields for 802.1P: (0-7) and VLAN Tag: (0-4094), both with a value of -1. A 'Next >' button is located at the bottom right of the form.

1. Under Internet Services

select **VDSL**.


2. Under Connection Type

select **PPPoE**.

3. Enter the details

Enter the details required for your specific **Connection Type**.

Using The First-Time Setup Wizard Wireless



The screenshot shows the NetComm wireless setup wizard. At the top, a progress bar indicates the current step is 'WIRELESS', with other steps being 'INTERNET', 'PHONE', 'GATEWAY SECURITY', 'TIMEZONE', and 'SUMMARY'. Below the progress bar, there are two sections: 'WIRELESS 2.4GHz' and 'WIRELESS 5GHz'. Each section has a radio button to toggle 'On' or 'Off'. For both sections, the 'Network Name' is 'NetComm 8218', the 'Security Key Type' is 'WPA2-PSK', and the 'WiFi Password' is 'Yiwapeqafi'. At the bottom right, there are '< Back' and 'Next >' buttons.

FOR A SEAMLESS WIFI EXPERIENCE

Please keep the same Network Names and WiFi Passwords for both the 2.4Ghz and 5Ghz networks settings.

1. On this page

You can configure the wireless networks of the gateway, Enter the **Network Name** (the name displayed on client devices when they scan for wireless networks), the **Security Key Type** (encryption type) and the **WiFi password**.

2. When you have finished

click the **Next >** button.

Using The First-Time Setup Wizard Phone



The image shows the NetComm First-Time Setup Wizard, specifically the 'PHONE' configuration step. At the top, the NetComm logo is displayed. Below it, a progress bar shows six steps: INTERNET, WIRELESS, PHONE (current), GATEWAY SECURITY, TIMEZONE, and SUMMARY. The 'PHONE' step is highlighted with a white dot. A note states: 'Note: Configuration of a telephone is optional. If you do not intend to use a telephone handset with your router, click the Next button below to skip this section.' The main area is divided into two columns: 'PHONE LINE 1' and 'PHONE LINE 2'. Each column contains input fields for: Phone Number, SIP Username, SIP Password, SIP Proxy Server, SIP Registrar Server, and SIP Outbound Proxy *. At the bottom, there is a note: '* Optional field, leave blank if you don't have this information.' and two buttons: '< Back' and 'Next >'.


1. Configuration of VoIP telephone is optional

If you do not intend to use a telephone handset with the gateway, click the **Next >** button to skip this section

2. To configure a telephone

Enter the details into the fields shown for each line you wish to use. If you do not know the values to enter, contact **More**. click the **Next >** button when you have finished.

Using The First-Time Setup Wizard Gateway Security



The screenshot shows the NetComm Gateway Security Setup Wizard. At the top is the NetComm logo. Below it is a progress bar with six steps: INTERNET, WIRELESS, PHONE, GATEWAY SECURITY (which is the current step and has a white dot), TIMEZONE, and SUMMARY. The main content area has a blue background. On the left, there is instructional text: 'To help protect the security of your network NetComm Wireless highly encourages you to change the default username and password for accessing your router. Please keep these details in a secure location, as you will need them to access the user interface of your device.' On the right, there are three input fields: 'New Login Username', 'New Login Password', and 'Confirm Login Password'. At the bottom right, there are two buttons: '< Back' and 'Next >'.

1. We highly recommend


that you configure a new username and password to access the gateway.

2. Usernames and passwords are case sensitive

can be up to 16 characters in length and may comprise letters, special characters and numbers without spaces.

When you have finished entering the new credentials, click the **Next >** button.

Using The First-Time Setup Wizard Timezone




1. Specify the timezone

where the gateway is located for correct time keeping and the log-keeping function of the gateway.

2. Click the Next > button

when you have chosen the correct timezone.

Using The First-Time Setup Wizard Summary



1. The wizard displays a summary of the entered information

Check that the details are correct. If they are correct, click the **Finish >** button.

If they are not, click the **< Back** button to go back to the relevant screen to make changes.

2. When you click the Finish > button

the gateway returns you to the **SUMMARY** page.